

ORDER CHECKLIST

SIDING AND ROOFING

Before finalizing your order, please make sure you have not forgotten the following items:

MS 1 | MS 1.1 | MS 1.2 | MS 2 | MS AUTHENTIC

Screws for profiles MS 1, MS 1.1, MS 1.2, MS 2, MS Authentic :

- Screw K-LATCH 1.25 in, century High-end - bag of 250 : N° A058.250
- Screw K-LATCH 1.25 in, self-drilling - bag of 250 : N° A053.250

Bending Tools

- Bending tool MAC 12'': N° ABP12
- Bending tool MAC 18'': N° ABP18
- Bending tool MAC 36'': N° ABP36

Snow guard

- North West : N° ABNNW
- Peak : N° ABNP
- Screw 2 in, color, bag of 250, socket 1/4'' : N° A056.250

Ventilation

- Ventilator, painted with the MAC colors : N° AVENT
- Ventilator, in MAC steel colors : N° AVENT.MAC
- Plumbing vent, in MAC steel colors : N° APLOMB

Paint

- Paint touch-up : N° A06

MS 3 | MS 4

Installation Bracket

- Brackets, required for the installation of MS 3 & MS 4 profiles : N° ABRA1

Screws for profiles MS 3, MS 4 :

- Screw K-LATCH 1.25 in, century High-end - bag of 250 : N° A058.250
- Screw K-LATCH 1.25 in, self-drilling - bag of 250 : N° A053.250

Bending Tools

- Bending tool MAC 12'': N° ABP12
- Bending tool MAC 18'': N° ABP18
- Bending tool MAC 36'': N° ABP36

Snow guard

- North West : N° ABNNW
- Peak : N° ABNP
- Screw 2 in, color, bag of 250, socket 1/4'' : N° A056.250

Ventilation

- Ventilator, painted with the MAC colors : N° AVENT
- Ventilator, in MAC steel colors : N° AVENT.MAC
- Plumbing vent, in MAC steel colors : N° APLOMB

Paint

- Paint touch-up : N° A06

MS 380 CORRUGATED | MS 750 | MS 750I

Screws for profile MS 380 :

- Screw 1 in, color, bag of 250 : N° A054.250
- Self-drilling color screw 1 in - bag of 250 (upon request) : N° A055.250

Screws for profiles MS 380, MS 750, MS 750I :

- Screw 2 in, color, bag of 250, socket 1/4'' : N° A056.250

Paint

- Paint touch-up : N° A06



HARRYWOOD | HARRYWOOD BLOCK | NORWOOD | NORWOOD MINI | MS 14

Moldings

- Starter Strip Norwood | Norwood Mini : N° M10D.10
- Starter Strip Harrywood | Harrywood Block : N° M10SHW.10
- Starter Strip MS 14 : N° M10S14.10

Screws for profiles Harrywood | Harrywood Block | Norwood | Norwood Mini | MS 14 :

- Wood Screw 1 1/8 in, MAC Anticorrosion, bag of 250 : N° A059.250
- Screw K-LATCH self-drilling 1 1/8 in, MAC Anticorrosion, bag of 250 : N° A060.250

MAC Cutter

- MAC Guillotine Norwood : N° A01NW
- MAC Guillotine Norwood Mini : N° A01NWM
- MAC Guillotine Harrywood | Harrywood Block : N° A01HW
- MAC Guillotine MS 14 : N° A01MS14

Paint

- Paint touch-up : N° A06

VERSA | METAL BLOCK

Moldings

- Starter strip Versa | Metal Block : N° M10G.10
- S Trim for, 12'', joint for horizontal installation : N° M16G
- Rigidity molding, 12'', for the reinforcement of sheets at the ends : N° ABRA3

Screws for profiles Versa | Metal Block :

- Screw K-LATCH 1.25 in, century High-end - bag of 250 : N° A058.250
- Screw K-LATCH 1.25 in, self-drilling - bag of 250 : N° A053.250

MAC Cutter

- MAC Guillotine Versa | Metal Block : N° A01VER

Bending Tools

- Bending tool MAC 12'': N° ABP12

Paint

- Paint touch-up : N° A06

POLYMAC

Moldings

- Starter Strip Polymac : N° M10G.10
- U-Trim molding (for fixing the panels) : N° M15P

Screws for profiles Polymac :

- Screw K-LATCH 1.25 in, century High-end - bag of 250 : N° A058.250
- Screw K-LATCH 1.25 in, self-drilling - bag of 250 : N° A053.250

Manual folder

- Polymac manual folder : N° A01POLY

Paint

- Paint touch-up : N° A06